



SPINETIX



Thank you for choosing HMP

Follow these easy steps to get started

Step 1: Connect Screen

You need a screen with an HDMI port and an HDMI cable (not included).

- 1 Connect one end of the HDMI cable to the HDMI port of your HMP.
- 2 Connect the other end of the HDMI cable to the HDMI port of the display device.

Step 2: Connect Network

You need an Ethernet cable (not included).

- 1 Connect one end of the Ethernet cable into the Ethernet port of your HMP.
- 2 Connect the other end of the Ethernet cable to the Ethernet port of a LAN-Switch or computer.

Step 3: Connect Power

HMP comes with a Power Supply Unit (PSU) and a line power cable.

- 1 Connect the DC power cable attached to the PSU to the DC input port of your HMP.
- 2 Connect the line power cable to the PSU.
- 3 Connect the other end of the line power cable into a power outlet.
- 4 Switch on the display device and the LAN-Switch or computer.

Step 4: Setup HMP

To set up your HMP, follow the on-screen instructions.

- 1 Push the blue button of your HMP.
- 2 Type the IP address shown on your screen in your browser's address bar.
- 3 Follow the instructions to complete the setup.
- 4 Once you complete the setup, your HMP will restart.

Elementi

HMP together with Elementi, our digital signage software, are the perfect choice for seamless integration.

Guides and Tech Specs

Guides, Tech Specs, and other docs are available under spinetix.com/docs.

Training and Certification

SpinetiX and SpinetiX Distributors offer Training and Certification programs dedicated to AV/IT installers and integrators worldwide.

More info is available under spinetix.com/academy.

Troubleshooting

Most problems can be solved quickly by following troubleshooting advice under support.spinetix.com.

Alternatively, you can contact your local SpinetiX Distributor or Dealer.

Tech Support

Extensive tech documentation is available under support.spinetix.com.

For further tech support, you can contact your local SpinetiX Distributor or Dealer.

Recycling and Disposing

Please recycle and dispose HMP responsibly, and according regulatory compliance in your country.

Legal

Terms and Conditions, Policies and Agreements related to DiVA are available under spinetix.com/legal.

COPYRIGHT © 2016 SPINETIX. ALL RIGHTS RESERVED.

SpinetiX and Hyper Media Player (HMP) are registered trademarks, and all logo and graphic designs are trademarks of SpinetiX AG.

Other product and company names appearing in SpinetiX products and materials are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.

Registered and unregistered trademarks used in any SpinetiX products and materials are the exclusive property of their respective owners.